

TABLE OF CONTENTS

2

MEANS OF REPRESENTATION	5	Adjusting the spring preload of the shock absorber	41
IMPORTANT NOTES	6	Adjusting the riding sag	42
SERIAL NUMBERS	7	Removing the shock absorber	43
Chassis number	7	Installing the shock absorber	43
Type label	7	Checking the shock absorber linkage	44
Engine number	7	Servicing the shock absorber	46
Fork part number	7	Removing the spring	46
Shock absorber part number	7	Disassembling the damper	47
MOTORCYCLE	8	Disassembling the piston rod	48
Raising the motorcycle with the lift stand	8	Disassembling the seal ring retainer	49
Removing the motorcycle from the lift stand	8	Changing the pilot bushing	49
Starting	8	Checking the damper	50
Starting the motorcycle for a check	9	Removing the heim joint	51
01/FORK, TRIPLE CLAMP	10	Installing the heim joint	52
Adjusting the compression damping of the fork	10	Assembling the seal ring retainer	52
Adjusting the rebound damping of the fork	10	Assembling the piston rod	53
Bleeding the fork legs	10	Assembling the damper	54
Cleaning the dust boots of the fork legs	11	Bleeding and filling the damper	56
Loosening the fork protection	11	Filling the damper with nitrogen	59
Positioning the fork protection	11	Installing the spring (350 SX-F EU)	59
Removing the fork legs	11	Installing the spring (350 SX-F USA)	60
Installing the fork legs	12	05/EXHAUST	62
Removing the fork protector	12	Removing the exhaust manifold	62
Installing the fork protector	13	Installing the exhaust manifold	62
Conducting major fork service	13	Removing the main silencer	63
Conducting minor fork service	13	Installing the main silencer	63
Disassembling the fork legs	14	Changing the glass fiber yarn filling of the main silencer ...	64
Disassembling the cartridge	16	06/AIR FILTER	65
Disassembling the piston rod	18	Removing the air filter box lid	65
Disassembling the screw cap with the membrane holder	20	Installing the air filter box lid	65
Disassembling the screw sleeve	21	Removing the air filter	65
Checking the fork legs	21	Installing the air filter	65
Checking the fork legs - during a minor fork service	23	Cleaning the air filter and air filter box	66
Changing the pilot bushing	24	07/FUEL TANK, SEAT, TRIM	67
Assembling the screw sleeve	24	Opening the filler cap	67
Reassembling the screw cap with the membrane holder	25	Closing the filler cap	67
Assembling the piston rod	26	Removing the seat	67
Assembling the cartridge	27	Mounting the seat	67
Assembling the fork legs	28	Removing the fuel tank	67
Bleeding and filling the cartridge	32	Installing the fuel tank	69
Filling the cartridge with nitrogen	33	Checking the fuel pressure	69
Greasing the steering head bearing	34	Changing the fuel filter	71
Removing the lower triple clamp	34	08/MASK, FENDER	74
Installing the lower triple clamp	34	Removing the front fender	74
Checking the steering head bearing play	36	Installing the front fender	74
Adjusting the play of the steering head bearing	36	Removing the start number plate	74
02/HANDLEBAR, INSTRUMENTS	37	Installing the start number plate	74
Handlebar position	37	09/FRONT WHEEL	75
Adjusting the handlebar position	37	Removing the front wheel	75
Adjusting the basic position of the clutch lever	37	Installing the front wheel	75
Checking the throttle cable routing	38	Checking the brake discs	76
Checking the play in the throttle cable	38	Removing the brake disc of the front brake	76
Adjusting the play in the throttle cable	38	Installing the brake disc of the front brake	77
04/SHOCK ABSORBER, SWINGARM	39	Checking the tire condition	77
Adjusting the high-speed compression damping of the shock absorber	39	Checking the tire air pressure	77
Adjusting the low-speed compression damping of the shock absorber	39	Checking the spoke tension	78
Adjusting the rebound damping of the shock absorber	40	10/REAR WHEEL	79
Measuring rear wheel sag unloaded	40	Removing the rear wheel	79
Checking the static sag of the shock absorber	41	Installing the rear wheel	79
Checking the riding sag of the shock absorber	41	Removing the brake disc of the rear brake	80
		Installing the brake disc of the rear brake	80

TABLE OF CONTENTS

3

Checking the chain tension	80	Removing the left section of the engine case.....	118
Adjusting the chain tension	81	Removing the shift rails	119
Adjusting the chain guide.....	82	Removing the shift drum.....	119
Checking the chain, rear sprocket, engine sprocket and chain guide.....	82	Removing the shift forks	119
Checking for chain dirt accumulation	84	Removing the transmission shafts	119
Cleaning the chain.....	84	Removing the crankshaft.....	120
11/WIRING HARNESS, BATTERY	85	30/ENGINE - WORK ON INDIVIDUAL PARTS.....	121
Removing the main fuse.....	85	Work on the right section of the engine case	121
Installing the main fuse	85	Working on the left section of the engine case.....	122
Removing the battery	85	Work on the clutch cover.....	123
Installing the battery.....	86	Checking the oil pressure regulator valve.....	124
Charging the battery	86	Checking the lubrication system.....	125
Checking the charging voltage	87	Removing the crankshaft bearing inner race	125
Checking the quiescent current.....	87	Installing the crankshaft bearing inner race.....	125
Checking the capacitor.....	88	Changing the connecting rod, conrod bearing and crank pin.....	126
Checking the starter relay.....	88	Checking the crankshaft run-out at the bearing pin	127
13/BRAKE SYSTEM.....	89	Removing the drive wheel of the balancer shaft.....	127
Checking the front brake linings.....	89	Installing the drive wheel of the balancer shaft.....	127
Changing the front brake linings	89	Cylinder - Nikasil® coating	128
Checking the free travel of the hand brake lever	90	Checking/measuring the cylinder.....	128
Adjusting the basic position of the hand brake lever.....	91	Checking/measuring the piston	128
Checking the front brake fluid level	91	Measuring the piston/cylinder mounting clearance	129
Adding front brake fluid	91	Checking the piston ring end gap	129
Changing the front brake fluid	92	Changing the camshaft bearing.....	130
Checking the rear brake linings.....	93	Checking the camshafts	130
Changing the rear brake linings.....	93	Checking the pivot points of the camshafts	131
Checking the free travel of foot brake lever.....	95	Removing the valves	132
Adjusting the basic position of the foot brake lever	95	Checking the valves	133
Checking the rear brake fluid level	95	Checking the valve springs	133
Adding rear brake fluid	96	Checking the valve spring seat	133
Changing the rear brake fluid.....	96	Checking the cam levers	133
30/ENGINE.....	98	Checking the cylinder head	134
Removing the engine	98	Installing the valves	134
Installing the engine	102	Checking the freewheel	135
30/DISASSEMBLING THE ENGINE.....	108	Checking the electric starter drive	136
Preparations.....	108	Checking the timing assembly	137
Removing the clutch push rod	108	Preparing the timing chain tensioner for installation	137
Removing the spacer	108	Checking the clutch.....	138
Draining the engine oil	108	Checking the shift mechanism.....	139
Removing the oil filter.....	109	Preassembling the shift shaft.....	140
Removing the spark plug	109	Disassembling the main shaft	141
Removing the valve cover	109	Disassembling the countershaft	141
Removing the starter motor	110	Checking the transmission.....	142
Positioning the engine at ignition top dead center.....	111	Assembling the main shaft	143
Removing the timing chain tensioner.....	111	Assembling the countershaft.....	144
Removing the camshaft.....	111	30/ASSEMBLING THE ENGINE	145
Removing the cylinder head.....	112	Installing the crankshaft.....	145
Removing the piston	112	Installing the transmission shafts	145
Removing the rotor	113	Installing the shift forks	145
Removing the starter drive.....	113	Installing the shift drum	146
Removing the suction pump	114	Installing the shift rails	146
Removing the water pump wheel.....	114	Installing the left engine case	146
Removing the clutch cover	115	Installing the spacer	147
Removing the clutch discs.....	115	Installing the timing chain.....	147
Removing the outer clutch hub	115	Installing the primary gear	147
Removing the shift shaft	116	Installing the force pump	148
Removing the shift drum locating unit	116	Installing the suction pump	148
Removing the force pump	116	Installing the shift drum locating unit	149
Removing the primary gear	117	Installing the shift shaft	149
Removing the timing chain	117	Installing the outer clutch hub.....	150
Removing the spacer	118	Installing the clutch discs	150

TABLE OF CONTENTS

4

Installing the clutch cover	151	CLEANING.....	186
Mounting the water pump cover	151	Cleaning the motorcycle.....	186
Installing the starter drive	152	STORAGE	187
Installing the rotor and ignition pulse generator	152	Storage.....	187
Installing the piston.....	152	Putting into operation after storage	187
Installing the cylinder head	154	SERVICE SCHEDULE.....	188
Installing the camshafts	155	Service schedule	188
Checking the valve timing	155	Service work (as additional order)....	189
Adjusting the valve timing	156	WIRING DIAGRAM	190
Installing the timing chain tensioner	157	Page 1 of 3.....	190
Checking the valve clearance	158	Page 2 of 3.....	192
Adjusting the valve clearance.....	158	Page 3 of 3.....	194
Installing the starter motor	159	SUBSTANCES.....	196
Installing the valve cover	160	AUXILIARY SUBSTANCES.....	198
Installing the spark plug.....	160	SPECIAL TOOLS.....	200
Installing the oil filter	160	STANDARDS.....	213
Installing the oil screen.....	161	INDEX.....	214
Installing the spacer	162		
Installing the clutch push rod	162		
Removing the engine from the work stand.....	162		
32/CLUTCH	163		
Checking the fluid level of the hydraulic clutch	163		
Changing the hydraulic clutch fluid	163		
35/WATER PUMP, COOLING SYSTEM	164		
Cooling system	164		
Checking the antifreeze and coolant level	164		
Checking the coolant level.....	164		
Draining the coolant	165		
Refilling coolant.....	166		
38/LUBRICATION SYSTEM	167		
Oil circuit	167		
Checking the engine oil level	167		
Changing the engine oil and oil filter, cleaning the oil screen	168		
Filling up with engine oil	169		
Adding engine oil	170		
39/IGNITION SYSTEM	171		
Ignition coil - checking the secondary winding.....	171		
Checking the spark plug connector.....	171		
Alternator - checking stator winding	171		
Removing the stator and ignition pulse generator.....	172		
Installing the stator and ignition pulse generator.....	172		
40/ELECTRIC STARTER.....	173		
Checking the starter motor	173		
41/THROTTLE VALVE BODY.....	174		
Throttle position sensor circuit A - checking the basic settings	174		
Throttle position sensor - adjusting the basic settings.....	174		
TECHNICAL DATA - ENGINE	176		
TECHNICAL DATA - TOLERANCE, WEAR LIMITS OF ENGINE	177		
TECHNICAL DATA - ENGINE TIGHTENING TORQUES.....	178		
TECHNICAL DATA - CHASSIS	180		
Lighting equipment	180		
Capacity - fuel.....	180		
Tires	181		
Capacity - fuel.....	181		
TECHNICAL DATA - FORK.....	182		
TECHNICAL DATA - SHOCK ABSORBER	183		
350 SX-F EU	183		
350 SX-F USA	183		
TECHNICAL DATA - CHASSIS TIGHTENING TORQUES	185		

MEANS OF REPRESENTATION

Symbols used

The symbols used are explained in the following.



Identifies an expected reaction (e.g. to a work step or a function).



Identifies an unexpected reaction (e.g. to a work step or a function).



Identifies a page reference (more information is provided on the specified page).



Indicates information with more details or tips.



Indicates the result of a testing step.



Identifies a voltage measurement.



Identifies a current measurement.



Identifies a resistance measurement.

Formats used

The typographical and other formats used are explained below.

Specific name

Identifies a proprietary name.

Name®

Identifies a protected name.

Brand™

Identifies a brand available on the open market.

IMPORTANT NOTES

Warranty

The work prescribed in the service schedule must be carried out by an authorized KTM workshop only and confirmed in the customer's service record and in the **KTM dealer.net**; otherwise, all warranty claims will be void. No warranty claims can be considered for damage resulting from manipulations and/or alterations to the vehicle.

Fuel, oils, etc.

You should use the fuels, oils and greases according to specifications as listed in the repair manual.

Spare parts, accessories

Only use spare parts and accessories approved and/or recommended by KTM. KTM accepts no liability for other products and any resulting damage or loss.

The current **KTM PowerParts** for your vehicle can be found on the KTM website.

International KTM Website: <http://www.ktm.com>

Work rules

Special tools are required for some work. These are not part of the vehicle standard equipment, but they can be ordered with the item number stated in parentheses. Ex.: bearing puller (15112017000)

When the vehicle is assembled, non-reusable parts (e.g., self-locking screws and nuts, gaskets, seal rings, O-rings, splints, lock washers) must be replaced with new parts.

Where thread lockers are used on screw connections (e.g., **Loctite®**), follow the instructions for use from the manufacturer.

After disassembly, clean the parts that are to be reused and check them for damage and wear. Replace damaged or worn parts.

After you complete the repair or maintenance work, check the roadworthiness of the vehicle.

Notes/warnings

Pay close attention to the notes/warnings.



Info

Various information and warning labels are affixed to the vehicle. Do not remove information/warning labels. If they are missing, you or others may not recognize potential hazards and may therefore be injured.

Grades of risks



Danger

Identifies a danger that will immediately and invariably lead to fatal or serious permanent injury if the appropriate measures are not taken.



Warning

Identifies a danger that is likely to lead to fatal or serious injury if the appropriate measures are not taken.



Caution

Identifies a danger that may lead to minor injuries if the appropriate measures are not taken.

Note

Identifies a danger that will lead to considerable machine and material damage if the appropriate measures are not taken.




Warning

Identifies a danger that will lead to environmental damage if the appropriate measures are not taken.

Repair manual


- It is imperative that you read this owner's manual carefully and completely before the start of work. It contains useful information and many tips on how to repair and maintain your vehicle.
- This manual assumes that the necessary special KTM tools and workplace and workshop equipment are available.

Chassis number




The chassis number ① is stamped on the right side of the steering head.

Type label




The type label ① is fixed to the front of the steering head.

Engine number




The engine number ① is stamped on the left side of the engine under the engine sprocket.

Fork part number



The fork part number ① is stamped on the inner side of the axle clamp.

Shock absorber part number




The shock absorber part number ① is stamped on the top of the shock absorber above the adjusting ring on the engine side.

Raising the motorcycle with the lift stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Raise the motorcycle at the frame underneath the engine.
- ✓ The wheels must no longer touch the ground.
- Secure the motorcycle against falling over.


Lift stand (54829055000) (☞ p. 200)

Removing the motorcycle from the lift stand

Note

Danger of damage The parked vehicle may roll away or fall over.

- Always place the vehicle on a firm and even surface.



- Remove the motorcycle from the lift stand.
- Remove the lift stand.
- To park the motorcycle, insert plug-in stand ① into the left side of the wheel spindle.



Info

Remove the plug-in stand before starting on a trip.

Starting



Danger


Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.

Note

Engine failure High engine speeds in cold engines have a negative effect on the service life of the engine.

- Always warm up the engine at low engine speeds.



- Remove the motorcycle from the stand.
- Shift gear to neutral.

Condition

Ambient temperature: < 20 °C (< 68 °F)

- Pull the idle speed adjusting screw all the way out.
- Press the electric starter button.



Info

Do not open the throttle to start.

Press the starter for a maximum of 5 seconds. Wait for at least 5 seconds before trying again.

Warning lamp **FL** lights up briefly as a functional control when starting.

Starting the motorcycle for a check



Danger

Danger of poisoning Exhaust gases are poisonous and inhaling them may result in unconsciousness and/or death.

- When running the engine, always make sure there is sufficient ventilation, and do not start or run the engine in an enclosed space without an effective exhaust extraction system.



Info

Press the starter for a maximum of 5 seconds. Wait for at least 5 seconds before trying again.



400733-01

- Shift gear to neutral.
- Press the electric starter button ①.



Info

Do not open the throttle.

Adjusting the compression damping of the fork



Info

The hydraulic compression damping determines the fork suspension behavior.



- Turn adjusting screws 1 clockwise all the way.



Info

Adjusting screws 1 are located at the top end of the fork legs.
Make the same adjustment on both fork legs.

- Turn back counterclockwise by the number of clicks corresponding to the fork type.
Guideline

Compression damping

Comfort	14 clicks
Standard	12 clicks
Sport	10 clicks



Info


Turn clockwise to increase damping; turn counterclockwise to reduce damping.

Adjusting the rebound damping of the fork



Info

The hydraulic rebound damping determines the fork suspension behavior.



- Remove protection caps 2.
- Turn adjusting screws 2 clockwise all the way.



Info

Adjusting screws 2 are located at the bottom end of the fork legs.
Make the same adjustment on both fork legs.

- Turn back counterclockwise by the number of clicks corresponding to the fork type.
Guideline

Rebound damping

Comfort	14 clicks
Standard	12 clicks
Sport	10 clicks



Info

Turn clockwise to increase damping; turn counterclockwise to reduce damping.

- Mount protection covers 2.

Bleeding the fork legs



- Raise the motorcycle with the lift stand. (☞ p. 8)
- Remove bleeder screws 1 briefly.
 - ✓ Any excess pressure escapes from the interior of the fork.
- Mount and tighten bleeder screws.
- Remove the motorcycle from the lift stand. (☞ p. 8)